


Features








- Induction Heating Element
- Residual Heat Indicator
- 9 Levels Power Stage Setting
- Automatic Safety Switch Off
- Touch Control
- Child Lock
- 4 Booster
- Timer
- Hood Function
- Pan Sensor
- Flexi Zone

Hood Features

- Air Flow at minimum speed: 198 m³/h
- Air Flow at maximum speed: 596 m³/h
- dB(max): 69,5
- 5 Levels Speed + Boost Speed

User Interface



Reference	Description
A 	Zone select key
B 	Child lock key
C 	ON/OFF key
D 	Power/Timer regulating key (Reduce) (Increase)
E 	Boost control key
F 	Timer key
G 	Hood control key

Using Your Hob

To start cooking;

1. Touch the ON/OFF (C) control key for 3 seconds.
2. Select the relevant zone (A) and setting by touching the regulating control key (D).

Note: If you don't choose a heat setting within 20 seconds, the induction hob will automatically switch off.

Child Lock Function;

To lock the controls:

1. Touch the key lock control for 3 seconds. The timer indicator will show "Lo".

To unlock the controls:

1. Make sure the Induction hob is turned on.
2. Touch and hold the key lock control for a while.

Booster Function;

Activated the boost function:

1. Select the zone by touching the zone select key (A).
2. Touching the boost control key (E), the zone indicator show "P" and the power reach max.

Cancel the boost function:

1. Touching the relevant zone select key (A).
2. Touching the regulating key (D) to cancel the Boost function, then the cooking zone returns to level 9.

Timer Function;

If you are not selecting any cooking zone:

1. Make sure at least one cooking is turned on and touch the timer key (F).
2. The minder indicator will start flashing and "10" will show in the timer display.
3. Set the time by touching "-" and "+" control of the timer.

Note: Touching the "-" and "+" together, the timer is cancelled and the timer indicator will turn off.

If the timer is set on one zone:

1. Select the relevant cooking zone which is working by touching the zone select key (A).
2. Press the timer key (F), the timing indicator flashes and you can set the timer.
3. Set the time by touching "-" and "+" control of the timer.

Note: Touching the "-" and "+" together, the timer is cancelled and the timer indicator will turn off.

Hood Function;

Activated the hood function:

You can activate the hood by pressing the hood key (G) then adjust the hood power level by pressing the regulating key (D).

Cancel the hood function:

You can deactivate the hood by pressing the hood key (G) then adjust the hood power level "0" by pressing the regulating "-" key (D).

When you have finished cooking;

Touching the slider regulating key (D) to decrease the power to "0" level.